

OIO-Link

41.4

Dimensions

Model Number

OBR12M-R101-2EP-IO-V31-L

Laser retroreflective sensor with 4-pin, M8 x 1 connector

Features

- Miniature design with versatile moun-• ting options
- DuraBeam Laser Sensors durable ٠ and employable like an LED
- Extended temperature range • -40°C ... 60°C
- High degree of protection IP69K
- IO-link interface for service and process data


Product information

The R101 series miniature optical sensors are the first devices of their kind to offer an end-to-end solution in a small single standard design - from thru-beam sensor through to a distance measurement device. As a result of this design, the sensors are able to perform practically all standard automation tasks.

The entire series enables sensors to communicate via IO-Link.

The DuraBeam laser sensors are durable and can be used in the same way as a standard sensor.

The use of Multi Pixel Technology gives the standard sensors a high level of flexibility and enables them to adapt more effectively to their operating environment.






Electrical connection





Indicators/operating means



1	Light-on/dark-on changeover switch
2	Sensitivity adjuster
3	Operating indicator / dark on
4	Signal indicator
5	Operating indicator / light on

€ **Pinout**

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



Pepperl+Fuchs Group

www.pepperl-fuchs.com

OBR12M-R101-2EP-IO-V31-L

Laserlabel

Technical data

General specifications Effective detection range Reflector distance Threshold detection range Reference target Light source Light type Polarization filter Laser nominal ratings Note Laser class Wave length Beam divergence Pulse length Repetition rate max. pulse energy Diameter of the light spot Angle of divergence Ambient light limit Functional safety related parameters MTTF_d Mission Time (T_M) **Diagnostic Coverage (DC)** Indicators/operating means Operation indicator

Function indicator Control elements Control elements Parameterization indicator Electrical specifications Operating voltage Ripple No-load supply current Protection class Interface Interface type Transfer rate **IO-Link Revision** Min. cycle time Process data witdh SIO mode support Device ID Compatible master port type Output Switching type

Signal output

Switching voltage Switching current Usage category Voltage drop Switching frequency Response time Ambient conditions

Ambient temperature Storage temperature Mechanical specifications

Degree of protection Connection Material Housing Optical face Mass

www.pepperl-fuchs.com

15 m H50 reflector laser diode modulated visible red light yes LASER LIGHT , DO NOT STARE INTO BEAM

680 nm > 5 mrad d63 < 2 mm in the range 250 ... 750 mm 1.6 μs max. 17.6 kHz 9.6 nJ approx. 30 mm at a distance of 12 m approx. 0.3 ° EN 60947-5-2

672 a 20 a 0 %

UB

 I_0

0 ... 12 m 0.2 ... 12 m

LED green: constantly on - power on flashing (4Hz) - short circuit flashing with short break (1 Hz) - IO-Link mode Yellow LED: Permanently lit—light path clear Permanently off—object detected Flashing (4 Hz)—operating reserve not reached Light-on/dark-on changeover switch sensitivity adjustment IO link communication: green LED goes out briefly (1 Hz)

10 ... 30 V DC max. 10 % < 20 mA at 24 V supply voltage

IO-Link (via C/Q = pin 4) COM 2 (38.4 kBaud) 1.1 2.3 ms Process data input 2 Bit Process data output 2 Bit yes 0x110202 (1114626)

Α

 U_d

f

The switching type of the sensor is adjustable. The default settina is: C/Q - Pin4: NPN normally open / dark-on, PNP normally closed / light-on, IO-Link /Q - Pin2: NPN normally closed / light-on, PNP normally open / dark-on 2 push-pull (4 in 1)outputs, short-circuit protected, reverse polarity protected, overvoltage protected max. 30 V DC max. 100 mA , resistive load DC-12 and DC-13 \leq 1.5 V DC 2000 Hz 250 µs -40 ... 60 °C (-40 ... 140 °F) -40 ... 70 °C (-40 ... 158 °F) IP67 / IP69 / IP69K M8 x 1 connector, 4-pin PC (Polycarbonate) **PMMA** approx. 10 g



Accessories

IO-Link-Master02-USB

IO-Link master, supply via USB port or separate power supply, LED indicators, M12 plug for sensor connection

REF-MH82

Reflector with Micro-structure, rectangular 82 mm x 60 mm, mounting holes

REF-MH50

Reflector with Micro-structure, rectangular 50.9 mm x 50.9 mm, mounting holes, fixing strap

REF-MVR10

Reflector with Micro-structure, rectangular 60 mm x 19 mm, mounting holes

REF-MH20

Reflector with Micro-structure, rectangular 32 mm x 20 mm, mounting holes

V31-GM-2M-PUR Female cordset, M8, 4-pin, PUR cable

V31-WM-2M-PUR Female cordset, M8, 4-pin, PUR cable

Other suitable accessories can be found at 8 www.pepperl-fuchs.com

Refer to "General Notes Relating to Pepperl+Fuchs Product Information"
Pepperl+Fuchs Group
USA: +1 330 486 0001
G

USA: +1 330 486 0001 G fa-info@us.pepperl-fuchs.com fa-

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com





Compliance with standards and directi-

ves			
Directive conformity			
EMC Directive 2004/108/EC	EN 60947-5-2:2007+A1:2012		
Standard conformity			
Product standard	EN 60947-5-2:2007+A1:2012 IEC 60947-5-2:2007 + A1:2012		
Standards	UL 60947-5-2: 2014 IEC 61131-9:2013 IEC 60825-1:2007 EN 60825-1:2007 EN 61131-9:2013		
Approvals and certificates			
UL approval	E87056 , cULus Listed , class 2 power supply , type rating 1		
FDA approval	IEC 60825-1:2007 Complies with 21 CFR 1040.10 and 1040.11 except for deviations pursuant to Laser Notice No. 50,		

dated June 24, 2007

Curves/Diagrams





To unlock the adjustment functions turn the sensing range adjuster for more than 180 degrees.



Sensing Range / Sensitivity

Turn sensing range / sensivity adjuster clockwise to increase sensing range / sensitivity.

Turn sensing range /sensivity adjuster counter clockwise to decrease sensing range / sensitivity.

If the end of the adjustment range is reached, the signal indicator starts flashing with 8 Hz.

Light-on / Dark-on Configuration

Press the light-on / dark-on changeover switch for more than 1 second (less than 4 seconds). The light-on / dark-on mode changes and the operating indicators are activated accordingly.

If you press the light-on / dark-on changeover switch for more than 4 seconds, the light-on / dark-on mode changes back to the original setting. On release of the light-on / dark-on changeover switch the current state is activated.

Restore Factory Settings

Press the light-on / dark-on changeover switch for more than 10 seconds (less than 30 seconds) until all LEDs turn off. On release of the light-on / dark-on changeover switch the signal indicator turns on. After 5 seconds the sensor resumes operation with factory default settings.

After 5 minutes of inactivity the sensing range / sensivity adjustment is locked. In order to reactivate the sensing range / sensivity adjustment, turn the sensing range / sensivity adjuster for more than 180 degrees.

Δ

